Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
DC-Silver aluminium case	Silver aluminium case with foam inserts for DC series transmitters	JMS-DC-AC	✓	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	
Silver aluminium case DCII	Silver aluminum case for DC transmitter	JMS-DCII-AC	✓	✓	✓	✓	√	✓	х	x	x	X	х	x	x	
Silver aluminium case DSII	Silver aluminium case with foam inserts for DS series transmitters.	JMS-DSII-AC	X	х	X	X	X	х	✓	√	✓	>	✓	√	✓	
Silver aluminium case DS	Silver aluminum case with foam inserts for DS series transmitters.	JMS-DS-AC	X	x	X	X	X	X	✓	√	✓	>	✓	√	✓	
Transmitter bag - DS	Protective bag with strap for DS series transmitters	JMS-DS-SC	X	x	X	X	x	X	✓	✓	✓	✓	✓	✓	<	
Case insert for DCII tray (red/silver)	Foam insert for aluminium case. This insert is suitable if you are inserting a DC series transmitter with a tray into the case.	JMS-DII-CIT	✓	✓	>	✓	>	✓	X	X	X	X	Х	X	х	
Thermo cover - DC	Cover to protect your hands and transmitter from cold and rainy weather.	JMS-DC-WG	✓	✓	>	>	>	✓	X	x	X	X	x	X	X	
Thermo cover - DS	Cover to protect your hands and transmitter from cold and rainy weather.	JMS-DS-WG	X	x	X	X	X	X	✓	✓	✓	>	✓	✓	✓	
Blue tray - DS16	Tray for DS series transmitters (except DS-12), matt blue finish.	JMS-DS-TBLUE	X	x	X	X	X	X	X	✓	✓	>	✓	X	x	
Black tray - DS-24	Tray for DS series transmitters (except DS-12), black glossy finish.	JMS-DS24-TBLACK	Х	х	X	X	X	X	X	✓	✓	✓	✓	√	<	
Blue tray - DS-24	Tray for DS series transmitters (except DS-12), matt blue finish.	JMS-DS24-TBLUE	X	х	X	X	X	X	X	√	✓	>	✓	√	✓	
Carbon design tray - DS-12	Tray for DS-12 transmitters.	JMS-DS12-PCD	X	х	X	X	X	X	✓	X	Х	X	х	X	x	
Black tray - DS-12	Tray for DS-12 transmitters, glossy black surface.	JMS-DS12-TBLACK	X	X	X	X	X	X	✓	X	X	X	X	X	X	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
carbon design tray	Plastic tray for DC series transmitters.	JMS-DC-PCD3	✓	<	>	>	>	<	x	x	X	X	x	x	X	
Black tray	Plastic tray with high gloss surface for DC series transmitters.	JMS-DC-TBLACK	✓	<	✓	✓	✓	<	х	X	x	X	х	X	X	
Blue tray	Tray made of transparent blue plastic for DC series transmitters.	JMS-DC-TBLUE	✓	✓	✓	✓	✓	✓	х	х	х	X	х	х	х	
Tray holder	Tray holder for attaching the transmitter and increasing the stability of the transmitter's mounting arms.	JMS-DC-HFT	√	✓	>	>	>	✓	X	X	X	X	X	X	х	
Pad	Self-adhesive flexible pad for comfortable hand position on the tray	JMS-DC-PPCD	✓	✓	>	✓	>	✓	X	X	X	X	X	X	X	
Transmitter bracket for strap	Foldable transmitter brackets for stable suspension without the use of a tray.	JMS-DC-B	✓	<	<	<	<	<	X	>	>	>	✓	✓	<	
Cross strap	Cross strap for convenient and stable hanging of the transmitter in the tray or with transmitter brackets.	JMS-DC-CS	✓	>	>	>	>	>	>	>	>	>	✓	✓	>	
Neck strap	Neck strap for hanging the transmitter in the counter or with brackets (2 points)	JMS-DC-NS	>	>	>	>	>	>	>	>	>	>	✓	✓	>	
Neck strap for DS-16	Neck strap for hanging DS series transmitters	JMS-DS-NS	X	X	X	X	X	X	>	>	>	>	✓	✓	>	
USB Mini cable	Data cable for Duplex transmitters (except DC/DS24II).	JMS-DC-KUSB	>	>	>	>	>	X	>	>	>	>	✓	✓	X	
USB C cable	Data and charging cable for Duplex DC/DS-24II transmitters. Length 1.5m.	JMS-TDx-KUSB-C	X	X	X	X	X	>	X	X	X	X	X	X	>	
Jack/Jack cable for teacher/student connection	Cable for connecting transmitters in teacher/student mode	JMS-DS-CJJT	✓	✓	>	>	>	✓	>		>		✓	✓	✓	
Power supply for DC/DS - universal	Power supply for all transmitters except DC24II	JMS-DC-PS-U	>	>	>	>	>	X	>	>	>	>	✓	✓	X	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
car socket power supply	Car socket charging adapter for Duplex transmitters (except DC/DS-24II).	JMS-DC-PC	✓	✓	>	✓	✓	x	✓	✓	✓	>	✓	✓	X	
Holder for DS tray	Tray holder for attaching the transmitter and increasing the stability of the transmitter mounting.	JMS-DS-HFT	Х	Х	X	X	Х	Х	✓	✓	✓	✓	✓	✓	✓	
Duplex bag	Bag for various uses	JMS-DS-DB	X	X	X	X	X	X	X	X	X	X	X	X	X	
controller stick	Long controller stick for DC transmitters.	JMS-DC-SS	✓	✓	✓	√	✓	✓	✓	✓	✓	✓	✓	✓	✓	For DS transmitters, it can be used to extend the sticks.
Mounting key - TX switch	Key for dismounting and replacing switches on the transmitter housing.	JMS-DC-SNS	✓	✓	✓	✓	√	✓	✓	✓	✓	✓	✓	√	✓	
DC - replaceable TX button	Button for mounting instead of a switch.	JMS-DC-TB	✓	✓	✓	✓	✓	✓	х	x	X	X	x	X	x	
DC-replaceable TX switch long 2	Two position switch with long stick for DC series transmitters.	JMS-DC-TSL2	√	✓	>	√	✓	✓	X	X	X	X	X	X	X	
DC-replaceable switch TX 2 lock	Two position switch with position lock for DC series transmitters.	JMS-DC-TSL2S	✓	✓	>	>	>	✓	X	X	X	X	X	X	X	
DC-replaceable TX switch long 3	Three position switch with long stick for DC series transmitters.	JMS-DC-TSL3	✓	✓	>	✓	✓	✓	x	X	X	X	x	X	X	
DC- replaceable switch TX long centre	Three-position switch with long stick that returns to the center position for DC series transmitters.	JMS-DC-TSLM	✓	✓	√	✓	✓	✓	x	X	X	X	x	X	X	
DC- replaceable switch TX long teacher	Two-position switch with long stick that returns to the upper position, for DC series transmitters.	JMS-DC-TSLT	✓	✓	>	✓	✓	✓	X	X	X	X	х	X	x	
DC- replaceable switch TX short 2	Two-position switch with short stick for DC series transmitters.	JMS-DC-TSS2	✓	✓	>	√	✓	✓	X	X	X	X	х	X	x	
DC-replaceable switch TX short 3	Three-position switch with short stick for DC series transmitters.	JMS-DC-TSS3	✓	✓	>	✓	✓	✓	X	X	X	X	X	X	X	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
DC- replaceable TX switch reversible down 3	Three-position switch with long stick that returns to the lower position, for DC series transmitters.	JMS-DC-TSSD	✓	✓	✓	✓	✓	✓	Х	X	X	X	X	Х	X	
DC- replaceable TX switch reversible up 3	Three position switch with long stick that returns to the upper position, for DC series transmitters.	JMS-DC-TSSU	✓	✓	✓	✓	✓	✓	x	X	x	X	x	x	x	
DC- black nut for front panel switches	Longer nut for securing switches on the front panel of the DC Series transmitter.	JMS-DC-NBT	>	✓	>	>	✓	>	Х	X	X	X	х	X	x	
DC24II - black nut for front panel switches	Nut for securing the switches on the front panel of the DC24II transmitter.	JMS-DC24II-NBT	X	X	X	X	X	>	X	X	X	X	X	X	x	
DC16 - silver nut for front panel switches	Silver nut for securing the switches on the front panel of the DC series transmitter.	JMS-DC-NST	>	✓	>	>	✓	>	X	X	X	X	X	X	x	
Rear metal cover for DC/DCII	Spare duralumin back cover for DC series transmitters	JMS-DC-BMC	>	✓	>	>	✓	>	X	X	X	X	X	X	x	
Plug	Plug for empty slot after the switch (5 pieces).	JMS-DC-BP	>	>	>	>	>	>	>	>	✓	>	✓	✓	>	
Back cover screws	Replacement set of DC transmitter cover screws.	JMS-DC-SBC	>	<	>	>	✓	✓	x	X	x	X	x	x	X	
DS12 back cover with button	The cover contains an MSW module and a button suitable for the F3K category. Up to five additional buttons or switches can be connected to the module.	JMS-DS12-RCF3K	x	X	x	X	X	x	✓	X	X	x	X	x	X	
controller stick	Short stick for DS series transmitters.	JMS-DS-SS	>	>	>	>	>	>	~	✓	✓	>	✓	✓	>	For DC transmitters, it can be used to shorten the sticks.
controller stick - button	Long controller stick with button.	JMS-DC-SB	>	✓	>	>	>	>	✓	✓	✓	>	✓	✓	>	
controller stick - potentiometer	Long controller stick with potentiometer.	JMS-DC-SP	>	✓	>	>	✓	>	✓	✓	✓	>	✓	✓	>	
controller stick - switch 2	Long controller stick with two-position switch.	JMS-DC-SS2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
controller stick - switch 3	Long controller stick with three-position switch.	JMS-DC-SS3	>	✓	>	>	>	>	>	>	>	>	✓	✓	✓	
Extended levers for side potentiometer	of the frame. (both sides)	JMS-DS-ESL	X	X	X	X	X	X	X	>	>	✓	✓	✓	✓	
Extended upward-facing side potentiometer slide levers	up. Allows accessibility of the side potentiometers when the DS transmitter is in the	JMS-DS16/24-ESL	X	X	X	X	X	X	x	√	✓	✓	✓	✓	✓	
DS replaceable TX button	Push button for mounting in place of the switch for DS series transmitters.	JMS-DS-TB	X	х	X	x	X	x	✓	√	√	✓	✓	✓	✓	
DS- replaceable switch TX long 2	Two position switch with long stick for DS series transmitters.	JMS-DS-TSL2	X	X	X	X	X	X	✓	>	>	✓	✓	✓	x	
DS- replaceable switch TX 2 lock	Two position switch with mechanical position lock for DS series transmitters.	JMS-DS-TSL2S	X	x	X	X	X	X	>	>	>	✓	✓	✓	X	
DS- replaceable switch TX long 3	Three-position switch with long stick for DS series transmitters.	JMS-DS-TSL3	X	X	X	X	X	X	>	>	>	>	✓	✓	X	
DS- replaceable switch TX long centre	Three-position switch with long stick that returns to the center position for DS series transmitters.	JMS-DS-TSLM	X	X	X	X	X	X	>	>	>	>	✓	✓	X	
DS- replaceable switch TX long teacher	Two-position switch with long stick that returns to the upper position for DS series transmitters.	JMS-DS-TSLT	X	X	X	X	X	X	>	>	>	>	✓	>	X	
DS- replaceable switch TX short 2	Two-position switch with short stick for DS series transmitters.	JMS-DS-TSS2	X	X	X	X	X	X	>	>	>	>	✓	✓	X	
DS- replaceable switch TX short 3	Three-position switch with short stick for DS series transmitters.	JMS-DS-TSS3	X	X	X	X	X	X	✓	>	>	✓	✓	✓	X	
DS- replaceable switch TX reversible down 3	Three-position switch with long stick that returns to the lower position for DS series transmitters.	JMS-DS-TSSD	X	X	X	X	X	X	✓	>	>	✓	✓	✓	X	
DS- replaceable switch TX reversible up 3	Three-position switch with long stick that returns to the upper position for DS series transmitters.	JMS-DS-TSSU	X	X	X	X	X	X	>	>	>	✓	✓	✓	X	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
	Set of screws for securing the rear cover of DS series transmitters (except DS-12).	JMS-DS-SBC	X	X	X	X	X	X	X	>	>	>	✓	>	✓	
Rear cover screws for DS-12	Set of screws for securing the rear cover of the DS-12 transmitter	JMS-DS12-SBC	X	X	X	X	X	X	>	X	X	X	x	X	X	
Side knob for DS 14/16/24 transmitters	A pair of spare side knobs.	JMS-DS-PSG	X	X	X	X	X	X	X	>	>	>	✓	>	X	
Aluminium pad	Metal pads for stable and vertical position of the transmitter.	JMS-DS-AF	X	X	X	X	X	X	X	>	>	>	✓	✓	✓	
Plastic pad	Plastic pads for stable and vertical positioning of the transmitter.	JMS-DS-PF	X	X	X	X	X	X	X	>	>	>	✓	>	✓	
DS-24 black nut for the front panel switches	Black nut for securing switches on the front panel of DS series transmitters (2pcs).	JMS-DS-NBTF	X	X	X	X	X	X	>	>	>	>	✓	>	>	
Silver nut for the front panel switches	Silver nut for securing switches on the front panel of DS series transmitters (2 pieces).	JMS-DS-NSTF	X	X	X	X	X	X	>	>	>	>	✓	>	>	
	Black nut for securing switches on the frame of DS series transmitters (2 pieces).	JMS-DS-NBTC	X	X	X	X	X	X	X	>	>	>	✓	>	>	
	Silver nut for securing switches on the frame of DS series transmitters (2 pieces).	JMS-DS-NSTC	X	X	X	X	X	X	X	✓	✓	✓	✓	√	✓	
Higher stiffness springs for cross controllers	Replaceable set of springs with higher stiffness for cross controllers.	JMS-DC-HTS	>	✓	>	>	>	✓	>	>	>	✓	✓	√	✓	
Standard stiffness springs for cross controllers	Replaceable set of springs with standard stiffness for cross controllers.	JMS-DC-STS	✓	✓	✓	✓	✓	>	✓	✓	✓	✓	✓	✓	✓	
Power Ion 6200	Spare accumulator for Duplex transmitters.	PI-6200-TX	√	✓	√	✓	√	✓	✓	✓	✓	√	✓	√	✓	
DC/DS24II MSW Expansion Module	Transmitter expansion module for six buttons or switches for DC/DS-24II transmitters.	JMS-TDX24II-MSW	X	X	X	X	X	✓	X	X	X	X	x	X	✓	

Name	Description	Code	DC-14	DC-14II	DC-16	DC-16II	DC-24	DC-24II	DS-12	DS-14	DS-14II	DS-16	DS-16II	DS-24	DS-24II	Note
DC/DS TDx MSW Expansion Module	Transmitter expansion module for six buttons or switches for DC/DS transmitters.	JMS-TDX-MSW	✓	✓	✓	✓	✓	x	✓	√	✓	✓	✓	√	X	
PPM to Jack-Tx black	Cable for outputting the PPM signal to the front panel of the transmitter	JMS-DC-KPPM-B	✓	x	√	х	х	х	х	√	х	✓	х	х	х	
PPM to Jack-Tx red	Cable for outputting the PPM signal to the front panel of the transmitter. Stereo for Phoenix simulator.	JMS-DC-KPPM-R	>	X	✓	X	X	X	X	>	X	>	X	X	X	
DUPLEX TX pad underlay	DUPLEX TX pad underlay	JMS-TDx-DP	✓	~	✓	<	<	<	<	✓	<	✓	<	✓	✓	